



General arrangement

737



737-600



General arrangement

737


737-700



General arrangement

737



737-800



General arrangement

737

737-900ER



Airstairs enable operations at airports with limited facilities

737

- Mounted under cabin floor just below the forward entry door
- Airstairs can be removed and stored when not in use for an extended period of time



- Optional feature.