



AIRPLANE RESCUE AND FIRE FIGHTING  
INFORMATION



Copyright © 2005  
The Boeing Company  
All Rights Reserved

### **Copyright Information**

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

The right to reproduce, distribute, display, and make derivative works from this document, or any portion thereof, requires a license from Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing 707, 717, 720, 727, 737, BBJ, P-8A, 747, 757, 767, 777, 787, C-17, DC-3, DC-6, DC-7, DC-8, DC-9, DC-10, KC-10A, MD-10, MD-11, MD-80, MD-90, the Boeing logo symbol, and the blue Boeing livery are all trademarks owned by The Boeing Company; and no trademark license (either expressed or implied) is granted in connection with this document or otherwise.

### **Document Information**

Any questions about the content or use of this manual should be directed to:

Manager, Flight Technical Integration & Data  
PO Box 3707, M/S 20-89  
Seattle, Washington 98124-2207 USA  
Telephone: 206-662-7700  
FAX: 206-662-78121  
Email: FTID@boeing.com

Information contained in this document, including illustrations, depicts the Boeing Company's standard airplane configuration. Diagrams are intended to be representative only. No attempt has been made to include customer variables or post-delivery modifications.

For training purposes, this document is available in viewfoil format, Adobe Portable Document Format (PDF) on CD, and individual pages are available as 2' x 3' black and white wall charts. For ordering information, please contact:

Boeing Commercial Airplanes  
Data and Services Management (DSM)  
PO Box 3707, Mail Stop 2H-65  
Seattle, Washington 98124-2207, USA  
Telephone: 206-544-5000  
FAX: 206-544-8899

Every attempt has been made to include as many of the Boeing Company's airplane configuration variables as possible.

Document Number: D6-7829

RevisionNumber: 5

RevisionDate: May 01, 2007

# AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

## Table of Contents

### 707

|  |         |
|--|---------|
| 707-100 & 200 SERIES .....                 | 707.0.1 |
| FLAMMABLE MATERIAL LOCATIONS .....         | 707.0.1 |
| EMERGENCY RESCUE ACCESS-1 .....            | 707.0.2 |
| EMERGENCY RESCUE ACCESS-2 .....            | 707.0.3 |
| BATTERY LOCATIONS .....                    | 707.0.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS ..... | 707.0.5 |
| 707-300 & 400 SERIES .....                 | 707.1.1 |
| FLAMMABLE MATERIAL LOCATIONS .....         | 707.1.1 |
| EMERGENCY RESCUE ACCESS-1 .....            | 707.1.2 |
| EMERGENCY RESCUE ACCESS-2 .....            | 707.1.3 |
| BATTERY LOCATIONS .....                    | 707.1.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS ..... | 707.1.5 |

### 717

|  |         |
|--|---------|
| 717 SERIES .....                           | 717.0.1 |
| FLAMMABLE MATERIAL LOCATIONS .....         | 717.0.1 |
| EMERGENCY RESCUE ACCESS-1 .....            | 717.0.2 |
| EMERGENCY RESCUE ACCESS-2 .....            | 717.0.3 |
| BATTERY LOCATIONS .....                    | 717.0.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS ..... | 717.0.5 |
| EXTERNAL APU FIRE CONTROLS .....           | 717.0.6 |
| COMPOSITE MATERIALS LOCATIONS .....        | 717.0.7 |

### 720

|  |         |
|--|---------|
| 720 & 720B SERIES .....                    | 720.0.1 |
| FLAMMABLE MATERIAL LOCATIONS .....         | 720.0.1 |
| EMERGENCY RESCUE ACCESS-1 .....            | 720.0.2 |
| EMERGENCY RESCUE ACCESS-2 .....            | 720.0.3 |
| BATTERY LOCATIONS .....                    | 720.0.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS ..... | 720.0.5 |

### 727

|  |         |
|--|---------|
| 727 SERIES .....                           | 727.0.1 |
| FLAMMABLE MATERIAL LOCATIONS .....         | 727.0.1 |
| EMERGENCY RESCUE ACCESS-1 .....            | 727.0.2 |
| EMERGENCY RESCUE ACCESS-2 .....            | 727.0.3 |
| BATTERY LOCATIONS .....                    | 727.0.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS ..... | 727.0.5 |
| COMPOSITE MATERIALS LOCATIONS .....        | 727.0.6 |

### 737

|  |         |
|--|---------|
| 737-100/200/300/400/500 SERIES .....       | 737.0.1 |
| FLAMMABLE MATERIAL LOCATIONS .....         | 737.0.1 |
| EMERGENCY RESCUE ACCESS-1 .....            | 737.0.2 |
| EMERGENCY RESCUE ACCESS-2 .....            | 737.0.3 |
| BATTERY LOCATIONS .....                    | 737.0.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS ..... | 737.0.5 |
| COMPOSITE MATERIALS LOCATIONS .....        | 737.0.6 |
| 737-600/700/800/900/ER/BBJ/BBJ-2 .....     | 737.1.1 |
| FLAMMABLE MATERIAL LOCATIONS .....         | 737.1.1 |
| EMERGENCY RESCUE ACCESS-1 .....            | 737.1.2 |
| EMERGENCY RESCUE ACCESS-2 .....            | 737.1.3 |
| BATTERY LOCATION .....                     | 737.1.4 |
| FLIGHT DECK CNTRL SWITCH LOCATIONS .....   | 737.1.5 |
| COMPOSITE MATERIALS LOCATIONS .....        | 737.1.6 |
| AUX TANK CAPACITIES .....                  | 737.1.7 |

### P-8A

|  |        |
|--|--------|
| P-8A .....                                 | P8.0.1 |
| GOVERNMENT PURPOSE AND RIGHTS .....        | P8.0.1 |
| GOVERNMENT PURPOSE AND RIGHTS .....        | P8.0.2 |
| FLAMMABLE MATERIAL LOCATIONS .....         | P8.0.3 |
| EMERGENCY RESCUE ACCESS-1 .....            | P8.0.4 |
| EMERGENCY RESCUE ACCESS-2 .....            | P8.0.5 |
| BATTERY LOCATION .....                     | P8.0.6 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS ..... | P8.0.7 |
| COMPOSITE MATERIALS LOCATIONS .....        | P8.0.8 |

### 747

|  |         |
|--|---------|
| 747-100 & 200/-100 & 200 COMBI .....       | 747.0.1 |
| FLAMMABLE MATERIAL LOCATIONS .....         | 747.0.1 |
| EMERGENCY RESCUE ACCESS-1 .....            | 747.0.2 |
| EMERGENCY RESCUE ACCESS-2 .....            | 747.0.3 |
| BATTERY LOCATIONS .....                    | 747.0.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS ..... | 747.0.5 |
| 747-200 SPECIAL FREIGHTER .....            | 747.1.1 |
| FLAMMABLE MATERIAL LOCATIONS .....         | 747.1.1 |
| EMERGENCY RESCUE ACCESS-1 .....            | 747.1.2 |
| EMERGENCY RESCUE ACCESS-2 .....            | 747.1.3 |
| BATTERY LOCATIONS .....                    | 747.1.4 |

# AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

## Table of Contents

|                                      |       |         |
|--------------------------------------|-------|---------|
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 747.1.5 |
| 747-300 & 300 COMBI SERIES           | ----- | 747.2.1 |
| FLAMMABLE MATERIAL LOCATIONS         | ----- | 747.2.1 |
| EMERGENCY RESCUE ACCESS-1            | ----- | 747.2.2 |
| EMERGENCY RESCUE ACCESS-2            | ----- | 747.2.3 |
| BATTERY LOCATIONS                    | ----- | 747.2.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 747.2.5 |
| 747-300 SPECIAL FREIGHTER            | ----- | 747.3.1 |
| FLAMMABLE MATERIAL LOCATIONS         | ----- | 747.3.1 |
| EMERGENCY RESCUE ACCESS-1            | ----- | 747.3.2 |
| EMERGENCY RESCUE ACCESS-2            | ----- | 747.3.3 |
| BATTERY LOCATIONS                    | ----- | 747.3.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 747.3.5 |
| 747 SP SERIES                        | ----- | 747.4.1 |
| FLAMMABLE MATERIAL LOCATIONS         | ----- | 747.4.1 |
| EMERGENCY RESCUE ACCESS-1            | ----- | 747.4.2 |
| EMERGENCY RESCUE ACCESS-2            | ----- | 747.4.3 |
| BATTERY LOCATIONS                    | ----- | 747.4.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 747.4.5 |
| 747 FREIGHTER SERIES                 | ----- | 747.5.1 |
| FLAMMABLE MATERIAL LOCATIONS         | ----- | 747.5.1 |
| EMERGENCY RESCUE ACCESS-1            | ----- | 747.5.2 |
| EMERGENCY RESCUE ACCESS-2            | ----- | 747.5.3 |
| BATTERY LOCATIONS                    | ----- | 747.5.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 747.5.5 |
| 747-400 & 400 COMBI SERIES           | ----- | 747.6.1 |
| FLAMMABLE MATERIAL LOCATIONS         | ----- | 747.6.1 |
| EMERGENCY RESCUE ACCESS-1            | ----- | 747.6.2 |
| EMERGENCY RESCUE ACCESS-2            | ----- | 747.6.3 |
| EMERGENCY RESCUE ACCESS-3            | ----- | 747.6.4 |
| EMERGENCY RESCUE ACCESS-4            | ----- | 747.6.5 |
| BATTERY LOCATIONS                    | ----- | 747.6.6 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 747.6.7 |
| 747-400 FREIGHTER SERIES             | ----- | 747.7.1 |
| FLAMMABLE MATERIAL LOCATIONS         | ----- | 747.7.1 |
| EMERGENCY RESCUE ACCESS-1            | ----- | 747.7.2 |
| EMERGENCY RESCUE ACCESS-2            | ----- | 747.7.3 |
| BATTERY LOCATIONS                    | ----- | 747.7.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 747.7.5 |

|                                      |       |         |
|--------------------------------------|-------|---------|
| COMPOSITE MATERIALS LOCATIONS        | ----- | 747.7.6 |
| 747 LARGE CARGO FREIGHTER            | ----- | 747.8.1 |
| FLAMMABLE MATERIAL LOCATIONS         | ----- | 747.8.1 |
| EMERGENCY RESCUE ACCESS-1            | ----- | 747.8.2 |
| EMERGENCY RESCUE ACCESS-2            | ----- | 747.8.3 |
| BATTERY LOCATIONS                    | ----- | 747.8.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 747.8.5 |
| COMPOSITE MATERIALS LOCATIONS        | ----- | 747.8.6 |

### 757

|                                      |       |         |
|--------------------------------------|-------|---------|
| 757-200 & 200 COMBI SERIES           | ----- | 757.0.1 |
| FLAMMABLE MATERIAL LOCATIONS         | ----- | 757.0.1 |
| EMERGENCY RESCUE ACCESS-1            | ----- | 757.0.2 |
| EMERGENCY RESCUE ACCESS-2            | ----- | 757.0.3 |
| BATTERY LOCATIONS                    | ----- | 757.0.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 757.0.5 |
| 757-200 PACKAGE FREIGHTER            | ----- | 757.1.1 |
| FLAMMABLE MATERIAL LOCATIONS         | ----- | 757.1.1 |
| EMERGENCY RESCUE ACCESS-1            | ----- | 757.1.2 |
| EMERGENCY RESCUE ACCESS-2            | ----- | 757.1.3 |
| BATTERY LOCATIONS                    | ----- | 757.1.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 757.1.5 |
| 757-300 SERIES                       | ----- | 757.2.1 |
| FLAMMABLE MATERIAL LOCATIONS         | ----- | 757.2.1 |
| EMERGENCY RESCUE ACCESS-1            | ----- | 757.2.2 |
| EMERGENCY RESCUE ACCESS-2            | ----- | 757.2.3 |
| BATTERY LOCATIONS                    | ----- | 757.2.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 757.2.5 |
| COMPOSITE MATERIALS LOCATIONS        | ----- | 757.2.6 |

### 767

|                                      |       |         |
|--------------------------------------|-------|---------|
| 767 SERIES                           | ----- | 767.0.1 |
| FLAMMABLE MATERIAL LOCATIONS         | ----- | 767.0.1 |
| EMERGENCY RESCUE ACCESS-1            | ----- | 767.0.2 |
| EMERGENCY RESCUE ACCESS-2            | ----- | 767.0.3 |
| BATTERY LOCATIONS                    | ----- | 767.0.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | ----- | 767.0.5 |
| COMPOSITE MATERIALS LOCATIONS        | ----- | 767.0.6 |

# AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

## Table of Contents

### 777

|                                      |          |
|--------------------------------------|----------|
| 777 SERIES                           | 777.0.1  |
| FLAMMABLE MATERIAL LOCATIONS         | 777.0.1  |
| EMERGENCY RESCUE ACCESS-1            | 777.0.2  |
| EMERGENCY RESCUE ACCESS-2            | 777.0.3  |
| EMERGENCY RESCUE ACCESS-3            | 777.0.4  |
| EMERGENCY RESCUE ACCESS-4            | 777.0.5  |
| EMERGENCY RESCUE ACCESS-5            | 777.0.6  |
| EMERGENCY RESCUE ACCESS-6            | 777.0.7  |
| BATTERY LOCATIONS                    | 777.0.8  |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | 777.0.9  |
| COMPOSITE MATERIALS LOCATIONS        | 777.0.10 |
| 777 FREIGHTER SERIES                 | 777.1.1  |
| FLAMMABLE MATERIAL LOCATIONS         | 777.1.1  |
| EMERGENCY RESCUE ACCESS-1            | 777.1.2  |
| EMERGENCY RESCUE ACCESS-2            | 777.1.3  |
| BATTERY LOCATIONS                    | 777.1.4  |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | 777.1.5  |
| COMPOSITE MATERIALS LOCATIONS        | 777.1.6  |

### 787

|                                      |         |
|--------------------------------------|---------|
| 787 SERIES                           | 787.0.1 |
| FLAMMABLE MATERIAL LOCATIONS         | 787.0.1 |
| EMERGENCY RESCUE ACCESS-1            | 787.0.2 |
| EMERGENCY RESCUE ACCESS-2            | 787.0.3 |
| EMERGENCY RESCUE ACCESS-3            | 787.0.4 |
| EMERGENCY RESCUE ACCESS-4            | 787.0.5 |
| EMERGENCY RESCUE ACCESS-5            | 787.0.6 |
| BATTERY LOCATIONS                    | 787.0.7 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | 787.0.8 |
| COMPOSITE MATERIALS LOCATIONS        | 787.0.9 |

### C-17

|                                      |         |
|--------------------------------------|---------|
| C-17/C-17 ER SERIES                  | C17.0.1 |
| FLAMMABLE MATERIAL LOCATIONS         | C17.0.1 |
| EMERGENCY RESCUE ACCESS-1            | C17.0.2 |
| EMERGENCY RESCUE ACCESS-2            | C17.0.3 |
| BATTERY LOCATIONS                    | C17.0.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | C17.0.5 |
| EXTERNAL APU FIRE CONTROLS           | C17.0.6 |

### DC-3

|                              |          |
|------------------------------|----------|
| DC3 SERIES                   | DC-3.0.1 |
| FLAMMABLE MATERIAL LOCATIONS | DC-3.0.1 |

### DC-6

|                              |          |
|------------------------------|----------|
| DC-6 SERIES                  | DC-6.0.1 |
| FLAMMABLE MATERIAL LOCATIONS | DC-6.0.1 |

### DC-7

|                              |          |
|------------------------------|----------|
| DC-7 SERIES                  | DC-7.0.1 |
| FLAMMABLE MATERIAL LOCATIONS | DC-7.0.1 |
| EMERGENCY RESCUE ACCESS      | DC-7.0.2 |
| EMERGENCY RESCUE ACCESS      | DC-7.0.3 |
| BATTERY LOCATIONS            | DC-7.0.4 |
| DC-7 FREIGHTER SERIES        | DC-7.1.1 |
| FLAMMABLE MATERIAL LOCATIONS | DC-7.1.1 |
| EMERGENCY RESCUE ACCESS-1    | DC-7.1.2 |
| EMERGENCY RESCUE ACCESS-2    | DC-7.1.3 |

### DC-8

|                              |          |
|------------------------------|----------|
| DC-8 SERIES                  | DC-8.0.1 |
| FLAMMABLE MATERIAL LOCATIONS | DC-8.0.1 |
| EMERGENCY RESCUE ACCESS-1    | DC-8.0.2 |
| EMERGENCY RESCUE ACCESS-2    | DC-8.0.3 |
| BATTERY LOCATIONS            | DC-8.0.4 |
| DC-8 FREIGHTER SERIES        | DC-8.1.1 |
| FLAMMABLE MATERIAL LOCATIONS | DC-8.1.1 |
| EMERGENCY RESCUE ACCESS-1    | DC-8.1.2 |
| EMERGENCY RESCUE ACCESS-2    | DC-8.1.3 |
| BATTERY LOCATIONS            | DC-8.1.4 |
| DC-8-61 SERIES               | DC-8.2.1 |
| FLAMMABLE MATERIAL LOCATIONS | DC-8.2.1 |
| EMERGENCY RESCUE ACCESS-1    | DC-8.2.2 |
| EMERGENCY RESCUE ACCESS-2    | DC-8.2.3 |
| BATTERY LOCATIONS            | DC-8.2.4 |
| DC-8-62 SERIES               | DC-8.3.1 |
| FLAMMABLE MATERIAL LOCATIONS | DC-8.3.1 |
| EMERGENCY RESCUE ACCESS-1    | DC-8.3.2 |
| EMERGENCY RESCUE ACCESS-2    | DC-8.3.3 |

# AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

## Table of Contents

|                                      |           |
|--------------------------------------|-----------|
| BATTERY LOCATIONS                    | DC-8.3.4  |
| DC-8-63 SERIES                       | DC-8.4.1  |
| FLAMMABLE MATERIAL LOCATIONS         | DC-8.4.1  |
| EMERGENCY RESCUE ACCESS-1            | DC-8.4.2  |
| EMERGENCY RESCUE ACCESS-2            | DC-8.4.3  |
| BATTERY LOCATIONS                    | DC-8.4.4  |
| DC-8-71 SERIES                       | DC-8.5.1  |
| FLAMMABLE MATERIAL LOCATIONS         | DC-8.5.1  |
| EMERGENCY RESCUE ACCESS-1            | DC-8.5.2  |
| EMERGENCY RESCUE ACCESS-2            | DC-8.5.3  |
| BATTERY LOCATIONS                    | DC-8.5.4  |
| DC-8-72 SERIES                       | DC-8.6.1  |
| FLAMMABLE MATERIAL LOCATIONS         | DC-8.6.1  |
| EMERGENCY RESCUE ACCESS-1            | DC-8.6.2  |
| EMERGENCY RESCUE ACCESS-2            | DC-8.6.3  |
| BATTERY LOCATIONS                    | DC-8.6.4  |
| DC-8-73 SERIES                       | DC-8.7.1  |
| FLAMMABLE MATERIAL LOCATIONS         | DC-8.7.1  |
| EMERGENCY RESCUE ACCESS-1            | DC-8.7.2  |
| EMERGENCY RESCUE ACCESS-2            | DC-8.7.3  |
| BATTERY LOCATIONS                    | DC-8.7.4  |
| <b>DC-9</b>                          |           |
| DC-9 SERIES                          | DC-9.0.1  |
| FLAMMABLE MATERIAL LOCATIONS         | DC-9.0.1  |
| EMERGENCY RESCUE ACCESS-1            | DC-9.0.2  |
| EMERGENCY RESCUE ACCESS-2            | DC-9.0.3  |
| BATTERY LOCATIONS                    | DC-9.0.4  |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | DC-9.0.5  |
| EXTERNAL APU FIRE CONTROLS           | DC-9.0.6  |
| <b>DC-10</b>                         |           |
| DC-10 SERIES                         | DC-10.0.1 |
| FLAMMABLE MATERIAL LOCATIONS         | DC-10.0.1 |
| EMERGENCY RESCUE ACCESS-1            | DC-10.0.2 |
| EMERGENCY RESCUE ACCESS-2            | DC-10.0.3 |
| EMERGENCY RESCUE ACCESS-3            | DC-10.0.4 |
| EMERGENCY RESCUE ACCESS-4            | DC-10.0.5 |
| BATTERY LOCATIONS                    | DC-10.0.6 |

|                                      |           |
|--------------------------------------|-----------|
| FLIGHT DECK CONTROL SWITCH LOCATIONS | DC-10.0.7 |
| EXTERNAL APU FIRE CONTROLS           | DC-10.0.8 |

### KC-10A

|                                      |            |
|--------------------------------------|------------|
| KC-10A SERIES                        | KC-10A.0.1 |
| FLAMMABLE MATERIAL LOCATIONS         | KC-10A.0.1 |
| EMERGENCY RESCUE ACCESS-1            | KC-10A.0.2 |
| EMERGENCY RESCUE ACCESS-2            | KC-10A.0.3 |
| EMERGENCY RESCUE ACCESS-3            | KC-10A.0.4 |
| BATTERY LOCATIONS                    | KC-10A.0.5 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | KC-10A.0.6 |
| EXTERNAL APU FIRE CONTROLS           | KC-10A.0.7 |

### MD-11

|                                      |           |
|--------------------------------------|-----------|
| MD-11 SERIES                         | MD-11.0.1 |
| FLAMMABLE MATERIAL LOCATIONS         | MD-11.0.1 |
| EMERGENCY RESCUE ACCESS-1            | MD-11.0.2 |
| EMERGENCY RESCUE ACCESS-2            | MD-11.0.3 |
| EMERGENCY RESCUE ACCESS-3            | MD-11.0.4 |
| EMERGENCY RESCUE ACCESS-4            | MD-11.0.5 |
| BATTERY LOCATIONS                    | MD-11.0.6 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | MD-11.0.7 |
| EXTERNAL APU FIRE CONTROLS           | MD-11.0.8 |

### MD-80

|                                      |           |
|--------------------------------------|-----------|
| MD-80 SERIES                         | MD-80.0.1 |
| FLAMMABLE MATERIAL LOCATIONS         | MD-80.0.1 |
| EMERGENCY RESCUE ACCESS-1            | MD-80.0.2 |
| EMERGENCY RESCUE ACCESS-2            | MD-80.0.3 |
| BATTERY LOCATIONS                    | MD-80.0.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | MD-80.0.5 |
| EXTERNAL APU FIRE CONTROLS           | MD-80.0.6 |

### MD-90

|                                      |           |
|--------------------------------------|-----------|
| MD-90 SERIES                         | MD-90.0.1 |
| FLAMMABLE MATERIAL LOCATIONS         | MD-90.0.1 |
| EMERGENCY RESCUE ACCESS-1            | MD-90.0.2 |
| EMERGENCY RESCUE ACCESS-2            | MD-90.0.3 |
| BATTERY LOCATIONS                    | MD-90.0.4 |
| FLIGHT DECK CONTROL SWITCH LOCATIONS | MD-90.0.5 |

**AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION**

**Table of Contents**

---

EXTERNAL APU FIRE CONTROLS ----- MD-90.0.6

**AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION**  
**Table of Contents**

---

Intentionally  
Blank

# AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

## List of Effective Pages

| Page                    | Date             |
|-------------------------|------------------|
| <b>ARFF</b>             |                  |
| * Title Page            | October 31, 2007 |
| * Copyright             | October 31, 2007 |
| TOC (tab)               |                  |
| * TOC.0.1-6             | October 31, 2007 |
| * LEP.0.1-2             | October 31, 2007 |
| * Revision Record.0.1-2 | October 31, 2007 |
| 707 (tab)               |                  |
| * 707.0.1-6             | October 31, 2007 |
| * 707.1.1-6             | October 31, 2007 |
| 717 (tab)               |                  |
| * 717.0.1-8             | October 31, 2007 |
| 720 (tab)               |                  |
| * 720.0.1-6             | October 31, 2007 |
| 727 (tab)               |                  |
| * 727.0.1-6             | October 31, 2007 |
| 737 (tab)               |                  |
| * 737.0.1-6             | October 31, 2007 |
| * 737.1.1-8             | October 31, 2007 |
| P8 (tab)                |                  |
| * P8.0.1-8              | October 31, 2007 |

| Page         | Date             |
|--------------|------------------|
| 747 (tab)    |                  |
| * 747.0.1-6  | October 31, 2007 |
| * 747.1.1-6  | October 31, 2007 |
| * 747.2.1-6  | October 31, 2007 |
| * 747.3.1-6  | October 31, 2007 |
| * 747.4.1-6  | October 31, 2007 |
| * 747.5.1-6  | October 31, 2007 |
| * 747.6.1-8  | October 31, 2007 |
| * 747.7.1-6  | October 31, 2007 |
| * 747.8.1-6  | October 31, 2007 |
| 757 (tab)    |                  |
| * 757.0.1-6  | October 31, 2007 |
| * 757.1.1-6  | October 31, 2007 |
| * 757.2.1-6  | October 31, 2007 |
| 767 (tab)    |                  |
| * 767.0.1-6  | October 31, 2007 |
| 777 (tab)    |                  |
| * 777.0.1-10 | October 31, 2007 |
| 777 (tab)    |                  |
| * 777.1.1-6  | October 31, 2007 |
| 787 (tab)    |                  |
| * 787.0.1-10 | October 31, 2007 |
| C17 (tab)    |                  |
| * C17.0.1-6  | October 31, 2007 |
| DC-3 (tab)   |                  |
| * DC-3.0.1-2 | October 31, 2007 |
| DC-6 (tab)   |                  |
| * DC-6.0.1-2 | October 31, 2007 |
| DC-7 (tab)   |                  |
| * DC-7.0.1-4 | October 31, 2007 |

| Page               | Date             |
|--------------------|------------------|
| DC-7 (tab)         |                  |
| * DC-7.1.1-4       | October 31, 2007 |
| DC-8 (tab)         |                  |
| * DC-8.0.1-4       | October 31, 2007 |
| * DC-8.1.1-4       | October 31, 2007 |
| * DC-8.2.1-4       | October 31, 2007 |
| * DC-8.3.1-4       | October 31, 2007 |
| * DC-8.4.1-4       | October 31, 2007 |
| * DC-8.5.1-4       | October 31, 2007 |
| * DC-8.6.1-4       | October 31, 2007 |
| * DC-8.7.1-4       | October 31, 2007 |
| DC-9 (tab)         |                  |
| * DC-9.0.1-6       | October 31, 2007 |
| DC-10 (tab)        |                  |
| * DC-10.0.1-8      | October 31, 2007 |
| KC-10A (tab)       |                  |
| * KC-10A.0.1-8     | October 31, 2007 |
| MD-11 (tab)        |                  |
| * MD-11.0.1-8      | October 31, 2007 |
| MD-80 (tab)        |                  |
| * MD-80.0.1-6      | October 31, 2007 |
| MD-90 (tab)        |                  |
| * MD-90.0.1-6      | October 31, 2007 |
| <b>(blank tab)</b> |                  |

**AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION**  
**List of Effective Pages**

---

Intentionally  
Blank

**AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION**

**Revision Record**

| <b>Model</b> | <b>Revision Item</b>   |
|--------------|--|
| ARFF         | This publication has been reformatted and revised since its previous release. Some of the previous information has been combined where it was redundant. New aircraft added are the 737ER, P-8, 747 Large Cargo Freighter, 777 Freighter Series and the 787. |

**AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION**  
**Revision Record**

---

Intentionally  
Blank