



AIRPLANE RESCUE AND FIRE FIGHTING
INFORMATION



Copyright © 2005
The Boeing Company
All Rights Reserved

Copyright Information

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

The right to reproduce, distribute, display, and make derivative works from this document, or any portion thereof, requires a license from Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing 707, 717, 720, 727, 737, BBJ, P-8A, 747, 757, 767, 777, 787, C-17, DC-3, DC-6, DC-7, DC-8, DC-9, DC-10, KC-10A, MD-10, MD-11, MD-80, MD-90, the Boeing logo symbol, and the blue Boeing livery are all trademarks owned by The Boeing Company; and no trademark license (either expressed or implied) is granted in connection with this document or otherwise.

Document Information

Any questions about the content or use of this manual should be directed to:

Manager, Flight Technical Data
Boeing Commercial Airplane Group
PO Box 3707, M/C 20-89
Seattle, Washington 98124-2207 USA

Information contained in this document, including illustrations, depicts the Boeing Company's standard airplane configuration. Diagrams are intended to be representative only. No attempt has been made to include customer variables or post-delivery modifications.

For training purposes, this document is available in viewfoil format, Adobe Portable Document Format (PDF) on CD, and individual pages are available as 2' x 3' black and white wall charts. For ordering information, please contact:

Boeing Commercial Airplanes
Data and Services Management (DSM)
PO Box 3707, Mail Stop 2H-65
Seattle, Washington 98124-2207, USA
Telephone: 206-544-5000
FAX: 206-544-8899

Every attempt has been made to include as many of the Boeing Company's airplane configuration variables as possible.

Document Number: D6-7829

RevisionNumber: 6

RevisionDate: October 31, 2009

AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

Table of Contents

707

707-100 & 200 SERIES	707.0.1
FLAMMABLE MATERIAL LOCATIONS	707.0.1
EMERGENCY RESCUE ACCESS-1	707.0.2
EMERGENCY RESCUE ACCESS-2	707.0.3
BATTERY LOCATIONS	707.0.4
FLIGHT DECK CONTROL SWITCH LOCATIONS	707.0.5
707-300 & 400 SERIES	707.1.1
FLAMMABLE MATERIAL LOCATIONS	707.1.1
EMERGENCY RESCUE ACCESS-1	707.1.2
EMERGENCY RESCUE ACCESS-2	707.1.3
BATTERY LOCATIONS	707.1.4
FLIGHT DECK CONTROL SWITCH LOCATIONS	707.1.5

717

717 SERIES	717.0.1
FLAMMABLE MATERIAL LOCATIONS	717.0.1
EMERGENCY RESCUE ACCESS-1	717.0.2
EMERGENCY RESCUE ACCESS-2	717.0.3
BATTERY LOCATIONS	717.0.4
FLIGHT DECK CONTROL SWITCH LOCATIONS	717.0.5
EXTERNAL APU FIRE CONTROLS	717.0.6
COMPOSITE MATERIALS LOCATIONS	717.0.7

720

720 & 720B SERIES	720.0.1
FLAMMABLE MATERIAL LOCATIONS	720.0.1
EMERGENCY RESCUE ACCESS-1	720.0.2
EMERGENCY RESCUE ACCESS-2	720.0.3
BATTERY LOCATIONS	720.0.4
FLIGHT DECK CONTROL SWITCH LOCATIONS	720.0.5

727

727 SERIES	727.0.1
FLAMMABLE MATERIAL LOCATIONS	727.0.1
EMERGENCY RESCUE ACCESS-1	727.0.2
EMERGENCY RESCUE ACCESS-2	727.0.3
BATTERY LOCATIONS	727.0.4
FLIGHT DECK CONTROL SWITCH LOCATIONS	727.0.5
COMPOSITE MATERIALS LOCATIONS	727.0.6

737

737-100/200/300/400/500 SERIES	737.0.1
FLAMMABLE MATERIAL LOCATIONS	737.0.1
EMERGENCY RESCUE ACCESS-1	737.0.2
EMERGENCY RESCUE ACCESS-2	737.0.3
BATTERY LOCATIONS	737.0.4
FLIGHT DECK CONTROL SWITCH LOCATIONS	737.0.5
COMPOSITE MATERIALS LOCATIONS	737.0.6
737-600/700/800/900/ER/BBJ/BBJ-2	737.1.1
FLAMMABLE MATERIAL LOCATIONS	737.1.1
EMERGENCY RESCUE ACCESS-1	737.1.2
EMERGENCY RESCUE ACCESS-2	737.1.3
BATTERY LOCATION	737.1.4
FLIGHT DECK CNTRL SWITCH LOCATIONS	737.1.5
COMPOSITE MATERIALS LOCATIONS	737.1.6
AUX TANK CAPACITIES	737.1.7

P-8A

P-8A	P8.0.1
GOVERNMENT PURPOSE AND RIGHTS	P8.0.1
GOVERNMENT PURPOSE AND RIGHTS	P8.0.2
FLAMMABLE MATERIAL LOCATIONS	P8.0.3
EMERGENCY RESCUE ACCESS-1	P8.0.4
EMERGENCY RESCUE ACCESS-2	P8.0.5
BATTERY LOCATION	P8.0.6
FLIGHT DECK CONTROL SWITCH LOCATIONS	P8.0.7
COMPOSITE MATERIALS LOCATIONS	P8.0.8

747

747-100 & 200/-100 & 200 COMBI	747.0.1
FLAMMABLE MATERIAL LOCATIONS	747.0.1
EMERGENCY RESCUE ACCESS-1	747.0.2
EMERGENCY RESCUE ACCESS-2	747.0.3
BATTERY LOCATIONS	747.0.4
FLIGHT DECK CONTROL SWITCH LOCATIONS	747.0.5
747-200 SPECIAL FREIGHTER	747.1.1
FLAMMABLE MATERIAL LOCATIONS	747.1.1
EMERGENCY RESCUE ACCESS-1	747.1.2
EMERGENCY RESCUE ACCESS-2	747.1.3
BATTERY LOCATIONS	747.1.4

AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

Table of Contents

FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	747.1.5	COMPOSITE MATERIALS LOCATIONS - - - - -	747.7.6
747-300 & 300 COMBI SERIES - - - - -	747.2.1	747 LARGE CARGO FREIGHTER - - - - -	747.8.1
FLAMMABLE MATERIAL LOCATIONS - - - - -	747.2.1	FLAMMABLE MATERIAL LOCATIONS - - - - -	747.8.1
EMERGENCY RESCUE ACCESS-1 - - - - -	747.2.2	EMERGENCY RESCUE ACCESS-1 - - - - -	747.8.2
EMERGENCY RESCUE ACCESS-2 - - - - -	747.2.3	EMERGENCY RESCUE ACCESS-2 - - - - -	747.8.3
BATTERY LOCATIONS - - - - -	747.2.4	BATTERY LOCATIONS - - - - -	747.8.4
FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	747.2.5	FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	747.8.5
747-300 SPECIAL FREIGHTER - - - - -	747.3.1	COMPOSITE MATERIALS LOCATIONS - - - - -	747.8.6
FLAMMABLE MATERIAL LOCATIONS - - - - -	747.3.1	747-8 FREIGHTER SERIES - - - - -	747.9.1
EMERGENCY RESCUE ACCESS-1 - - - - -	747.3.2	FLAMMABLE MATERIAL LOCATIONS - - - - -	747.9.1
EMERGENCY RESCUE ACCESS-2 - - - - -	747.3.3	EMERGENCY RESCUE ACCESS-1 - - - - -	747.9.2
BATTERY LOCATIONS - - - - -	747.3.4	EMERGENCY RESCUE ACCESS-2 - - - - -	747.9.3
FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	747.3.5	BATTERY LOCATIONS - - - - -	747.9.4
747 SP SERIES - - - - -	747.4.1	FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	747.9.5
FLAMMABLE MATERIAL LOCATIONS - - - - -	747.4.1	COMPOSITE MATERIALS LOCATIONS - - - - -	747.9.6
EMERGENCY RESCUE ACCESS-1 - - - - -	747.4.2		
EMERGENCY RESCUE ACCESS-2 - - - - -	747.4.3	757	
BATTERY LOCATIONS - - - - -	747.4.4	757-200 & 200 COMBI SERIES - - - - -	757.0.1
FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	747.4.5	FLAMMABLE MATERIAL LOCATIONS - - - - -	757.0.1
747 FREIGHTER SERIES - - - - -	747.5.1	EMERGENCY RESCUE ACCESS-1 - - - - -	757.0.2
FLAMMABLE MATERIAL LOCATIONS - - - - -	747.5.1	EMERGENCY RESCUE ACCESS-2 - - - - -	757.0.3
EMERGENCY RESCUE ACCESS-1 - - - - -	747.5.2	BATTERY LOCATIONS - - - - -	757.0.4
EMERGENCY RESCUE ACCESS-2 - - - - -	747.5.3	FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	757.0.5
BATTERY LOCATIONS - - - - -	747.5.4	757-200 PACKAGE FREIGHTER - - - - -	757.1.1
FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	747.5.5	FLAMMABLE MATERIAL LOCATIONS - - - - -	757.1.1
747-400 & 400 COMBI SERIES - - - - -	747.6.1	EMERGENCY RESCUE ACCESS-1 - - - - -	757.1.2
FLAMMABLE MATERIAL LOCATIONS - - - - -	747.6.1	EMERGENCY RESCUE ACCESS-2 - - - - -	757.1.3
EMERGENCY RESCUE ACCESS-1 - - - - -	747.6.2	BATTERY LOCATIONS - - - - -	757.1.4
EMERGENCY RESCUE ACCESS-2 - - - - -	747.6.3	FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	757.1.5
EMERGENCY RESCUE ACCESS-3 - - - - -	747.6.4	757-300 SERIES - - - - -	757.2.1
EMERGENCY RESCUE ACCESS-4 - - - - -	747.6.5	FLAMMABLE MATERIAL LOCATIONS - - - - -	757.2.1
BATTERY LOCATIONS - - - - -	747.6.6	EMERGENCY RESCUE ACCESS-1 - - - - -	757.2.2
FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	747.6.7	EMERGENCY RESCUE ACCESS-2 - - - - -	757.2.3
747-400 FREIGHTER SERIES - - - - -	747.7.1	BATTERY LOCATIONS - - - - -	757.2.4
FLAMMABLE MATERIAL LOCATIONS - - - - -	747.7.1	FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	757.2.5
EMERGENCY RESCUE ACCESS-1 - - - - -	747.7.2	COMPOSITE MATERIALS LOCATIONS - - - - -	757.2.6
EMERGENCY RESCUE ACCESS-2 - - - - -	747.7.3		
BATTERY LOCATIONS - - - - -	747.7.4		
FLIGHT DECK CONTROL SWITCH LOCATIONS - - - - -	747.7.5		

AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

Table of Contents

767

767 SERIES	767.0.1
FLAMMABLE MATERIAL LOCATIONS	767.0.1
EMERGENCY RESCUE ACCESS-1	767.0.2
EMERGENCY RESCUE ACCESS-2	767.0.3
BATTERY LOCATIONS	767.0.4
FLIGHT DECK CONTROL SWITCH LOCATIONS	767.0.5
COMPOSITE MATERIALS LOCATIONS	767.0.6

777

777 SERIES	777.0.1
FLAMMABLE MATERIAL LOCATIONS	777.0.1
EMERGENCY RESCUE ACCESS-1	777.0.2
EMERGENCY RESCUE ACCESS-2	777.0.3
EMERGENCY RESCUE ACCESS-3	777.0.4
EMERGENCY RESCUE ACCESS-4	777.0.5
EMERGENCY RESCUE ACCESS-5	777.0.6
EMERGENCY RESCUE ACCESS-6	777.0.7
BATTERY LOCATIONS	777.0.8
FLIGHT DECK CONTROL SWITCH LOCATIONS	777.0.9
COMPOSITE MATERIALS LOCATIONS	777.0.10
777 FREIGHTER SERIES	777.1.1
FLAMMABLE MATERIAL LOCATIONS	777.1.1
EMERGENCY RESCUE ACCESS-1	777.1.2
EMERGENCY RESCUE ACCESS-2	777.1.3
BATTERY LOCATIONS	777.1.4
FLIGHT DECK CONTROL SWITCH LOCATIONS	777.1.5
COMPOSITE MATERIALS LOCATIONS	777.1.6

787

787 SERIES	787.0.1
FLAMMABLE MATERIAL LOCATIONS	787.0.1
EMERGENCY RESCUE ACCESS-1	787.0.2
EMERGENCY RESCUE ACCESS-2	787.0.3
EMERGENCY RESCUE ACCESS-3	787.0.4
EMERGENCY RESCUE ACCESS-4	787.0.5
EMERGENCY RESCUE ACCESS-5	787.0.6
BATTERY LOCATIONS	787.0.7
FLIGHT DECK CONTROL SWITCH LOCATIONS	787.0.8
COMPOSITE MATERIALS LOCATIONS	787.0.9

C-17

C-17/C-17 ER SERIES	C17.0.1
FLAMMABLE MATERIAL LOCATIONS	C17.0.1
EMERGENCY RESCUE ACCESS-1	C17.0.2
EMERGENCY RESCUE ACCESS-2	C17.0.3
BATTERY LOCATIONS	C17.0.4
FLIGHT DECK CONTROL SWITCH LOCATIONS	C17.0.5
EXTERNAL APU FIRE CONTROLS	C17.0.6

DC-3

DC3 SERIES	DC-3.0.1
FLAMMABLE MATERIAL LOCATIONS	DC-3.0.1

DC-6

DC-6 SERIES	DC-6.0.1
FLAMMABLE MATERIAL LOCATIONS	DC-6.0.1

DC-7

DC-7 SERIES	DC-7.0.1
FLAMMABLE MATERIAL LOCATIONS	DC-7.0.1
EMERGENCY RESCUE ACCESS	DC-7.0.2
EMERGENCY RESCUE ACCESS	DC-7.0.3
BATTERY LOCATIONS	DC-7.0.4
DC-7 FREIGHTER SERIES	DC-7.1.1
FLAMMABLE MATERIAL LOCATIONS	DC-7.1.1
EMERGENCY RESCUE ACCESS-1	DC-7.1.2
EMERGENCY RESCUE ACCESS-2	DC-7.1.3

DC-8

DC-8 SERIES	DC-8.0.1
FLAMMABLE MATERIAL LOCATIONS	DC-8.0.1
EMERGENCY RESCUE ACCESS-1	DC-8.0.2
EMERGENCY RESCUE ACCESS-2	DC-8.0.3
BATTERY LOCATIONS	DC-8.0.4
DC-8 FREIGHTER SERIES	DC-8.1.1
FLAMMABLE MATERIAL LOCATIONS	DC-8.1.1
EMERGENCY RESCUE ACCESS-1	DC-8.1.2
EMERGENCY RESCUE ACCESS-2	DC-8.1.3
BATTERY LOCATIONS	DC-8.1.4

AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

Table of Contents

DC-8-61 SERIES -----	DC-8.2.1	DC-10	
FLAMMABLE MATERIAL LOCATIONS -----	DC-8.2.1	DC-10 SERIES -----	DC-10.0.1
EMERGENCY RESCUE ACCESS-1 -----	DC-8.2.2	FLAMMABLE MATERIAL LOCATIONS -----	DC-10.0.1
EMERGENCY RESCUE ACCESS-2 -----	DC-8.2.3	EMERGENCY RESCUE ACCESS-1 -----	DC-10.0.2
BATTERY LOCATIONS -----	DC-8.2.4	EMERGENCY RESCUE ACCESS-2 -----	DC-10.0.3
DC-8-62 SERIES -----	DC-8.3.1	EMERGENCY RESCUE ACCESS-3 -----	DC-10.0.4
FLAMMABLE MATERIAL LOCATIONS -----	DC-8.3.1	EMERGENCY RESCUE ACCESS-4 -----	DC-10.0.5
EMERGENCY RESCUE ACCESS-1 -----	DC-8.3.2	BATTERY LOCATIONS -----	DC-10.0.6
EMERGENCY RESCUE ACCESS-2 -----	DC-8.3.3	FLIGHT DECK CONTROL SWITCH LOCATIONS ----	DC-10.0.7
BATTERY LOCATIONS -----	DC-8.3.4	EXTERNAL APU FIRE CONTROLS -----	DC-10.0.8
DC-8-63 SERIES -----	DC-8.4.1	KC-10A	
FLAMMABLE MATERIAL LOCATIONS -----	DC-8.4.1	KC-10A SERIES -----	KC-10A.0.1
EMERGENCY RESCUE ACCESS-1 -----	DC-8.4.2	FLAMMABLE MATERIAL LOCATIONS -----	KC-10A.0.1
EMERGENCY RESCUE ACCESS-2 -----	DC-8.4.3	EMERGENCY RESCUE ACCESS-1 -----	KC-10A.0.2
BATTERY LOCATIONS -----	DC-8.4.4	EMERGENCY RESCUE ACCESS-2 -----	KC-10A.0.3
DC-8-71 SERIES -----	DC-8.5.1	EMERGENCY RESCUE ACCESS-3 -----	KC-10A.0.4
FLAMMABLE MATERIAL LOCATIONS -----	DC-8.5.1	BATTERY LOCATIONS -----	KC-10A.0.5
EMERGENCY RESCUE ACCESS-1 -----	DC-8.5.2	FLIGHT DECK CONTROL SWITCH LOCATIONS ---	KC-10A.0.6
EMERGENCY RESCUE ACCESS-2 -----	DC-8.5.3	EXTERNAL APU FIRE CONTROLS -----	KC-10A.0.7
BATTERY LOCATIONS -----	DC-8.5.4	MD-11	
DC-8-72 SERIES -----	DC-8.6.1	MD-11 SERIES -----	MD-11.0.1
FLAMMABLE MATERIAL LOCATIONS -----	DC-8.6.1	FLAMMABLE MATERIAL LOCATIONS -----	MD-11.0.1
EMERGENCY RESCUE ACCESS-1 -----	DC-8.6.2	EMERGENCY RESCUE ACCESS-1 -----	MD-11.0.2
EMERGENCY RESCUE ACCESS-2 -----	DC-8.6.3	EMERGENCY RESCUE ACCESS-2 -----	MD-11.0.3
BATTERY LOCATIONS -----	DC-8.6.4	EMERGENCY RESCUE ACCESS-3 -----	MD-11.0.4
DC-8-73 SERIES -----	DC-8.7.1	EMERGENCY RESCUE ACCESS-4 -----	MD-11.0.5
FLAMMABLE MATERIAL LOCATIONS -----	DC-8.7.1	BATTERY LOCATIONS -----	MD-11.0.6
EMERGENCY RESCUE ACCESS-1 -----	DC-8.7.2	FLIGHT DECK CONTROL SWITCH LOCATIONS ----	MD-11.0.7
EMERGENCY RESCUE ACCESS-2 -----	DC-8.7.3	EXTERNAL APU FIRE CONTROLS -----	MD-11.0.8
BATTERY LOCATIONS -----	DC-8.7.4	MD-80	
DC-9		MD-80 SERIES -----	MD-80.0.1
DC-9 SERIES -----	DC-9.0.1	FLAMMABLE MATERIAL LOCATIONS -----	MD-80.0.1
FLAMMABLE MATERIAL LOCATIONS -----	DC-9.0.1	EMERGENCY RESCUE ACCESS-1 -----	MD-80.0.2
EMERGENCY RESCUE ACCESS-1 -----	DC-9.0.2	EMERGENCY RESCUE ACCESS-2 -----	MD-80.0.3
EMERGENCY RESCUE ACCESS-2 -----	DC-9.0.3	BATTERY LOCATIONS -----	MD-80.0.4
BATTERY LOCATIONS -----	DC-9.0.4	FLIGHT DECK CONTROL SWITCH LOCATIONS ----	MD-80.0.5
FLIGHT DECK CONTROL SWITCH LOCATIONS ----	DC-9.0.5	EXTERNAL APU FIRE CONTROLS -----	MD-80.0.6
EXTERNAL APU FIRE CONTROLS -----	DC-9.0.6		

AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

Table of Contents

MD-90

MD-90 SERIES	MD-90.0.1
FLAMMABLE MATERIAL LOCATIONS	MD-90.0.1
EMERGENCY RESCUE ACCESS-1	MD-90.0.2
EMERGENCY RESCUE ACCESS-2	MD-90.0.3
BATTERY LOCATIONS	MD-90.0.4
FLIGHT DECK CONTROL SWITCH LOCATIONS ---	MD-90.0.5
EXTERNAL APU FIRE CONTROLS	MD-90.0.6

AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION
Table of Contents

Intentionally
Blank

AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

List of Effective Pages

Page	Date
ARFF	
* Title Page	October 31, 2009
* Copyright	October 31, 2009
TOC (tab)	
* TOC.0.1-6	October 31, 2009
* LEP.0.1-2	October 31, 2009
* Revision Record.0.1-2	October 31, 2009
707 (tab)	
* 707.0.1-6	October 31, 2009
* 707.1.1-6	October 31, 2009
717 (tab)	
* 717.0.1-8	October 31, 2009
720 (tab)	
* 720.0.1-6	October 31, 2009
727 (tab)	
* 727.0.1-6	October 31, 2009
737 (tab)	
* 737.0.1-6	October 31, 2009
* 737.1.1-8	October 31, 2009
P8 (tab)	
* P8.0.1-8	October 31, 2009

Page	Date
747 (tab)	
* 747.0.1-6	October 31, 2009
* 747.1.1-6	October 31, 2009
* 747.2.1-6	October 31, 2009
* 747.3.1-6	October 31, 2009
* 747.4.1-6	October 31, 2009
* 747.5.1-6	October 31, 2009
* 747.6.1-8	October 31, 2009
* 747.7.1-6	October 31, 2009
* 747.8.1-6	October 31, 2009
* 747.9.1-6	October 31, 2009
757 (tab)	
* 757.0.1-6	October 31, 2009
* 757.1.1-6	October 31, 2009
* 757.2.1-6	October 31, 2009
767 (tab)	
* 767.0.1-6	October 31, 2009
777 (tab)	
* 777.0.1-10	October 31, 2009
777 (tab)	
* 777.1.1-6	October 31, 2009
787 (tab)	
* 787.0.1-10	October 31, 2009
C17 (tab)	
* C17.0.1-6	October 31, 2009
DC-3 (tab)	
* DC-3.0.1-2	October 31, 2009
DC-6 (tab)	
* DC-6.0.1-2	October 31, 2009
DC-7 (tab)	
* DC-7.0.1-4	October 31, 2009

Page	Date
DC-7 (tab)	
* DC-7.1.1-4	October 31, 2009
DC-8 (tab)	
* DC-8.0.1-4	October 31, 2009
* DC-8.1.1-4	October 31, 2009
* DC-8.2.1-4	October 31, 2009
* DC-8.3.1-4	October 31, 2009
* DC-8.4.1-4	October 31, 2009
* DC-8.5.1-4	October 31, 2009
* DC-8.6.1-4	October 31, 2009
* DC-8.7.1-4	October 31, 2009
DC-9 (tab)	
* DC-9.0.1-6	October 31, 2009
DC-10 (tab)	
* DC-10.0.1-8	October 31, 2009
KC-10A (tab)	
* KC-10A.0.1-8	October 31, 2009
MD-11 (tab)	
* MD-11.0.1-8	October 31, 2009
MD-80 (tab)	
* MD-80.0.1-6	October 31, 2009
MD-90 (tab)	
* MD-90.0.1-6	October 31, 2009
(blank tab)	

AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION
List of Effective Pages

**Intentionally
Blank**

AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION

Revision Record

Model	Revision Item
All	FLAMMABLE MATERIAL LOCATIONS - Added CAUTION note to all models cautioning rescue crews to use caution when moving across possible weakened aircraft sections due to fatigue or fire.
P-8A	FLAMMABLE MATERIAL LOCATIONS - Corrected main fuel tank fuel quantity numbers.
747-400 Freighter	FLAMMABLE MATERIAL LOCATIONS - Corrected main fuel tank fuel quantity numbers. EMERGENCY RESCUE ACCESS-2 - Removed incorrect reference to aft entry door. FLIGHT DECK CONTROL SWITCH LOCATIONS - Corrected fire panel switch graphic.
747-8	Added new 747-8 chapter/section.
787	EMERGENCY RESCUE ACCESS-1 - Reversed direction of DOOR OPEN arrow. BATTERY LOCATIONS - Added Aft E&E Compartment graphic. FLIGHT DECK CONTROL SWITCH LOCATIONS - Enlarged panels for readability.

AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION
Revision Record

Intentionally
Blank