

**P-8A**

**GOVERNMENT PURPOSE AND RIGHTS**

Contract No.: N00019-04-C-3146

Contractor: The Boeing Company and/or subcontractor/supplier asserting rights.

Contractor Address: P.O. Box 3707, 7755 E. Marginal Way, Seattle, WA 98124

Expiration Date: 14 June 2009

The Government's rights to use, modify, reproduce, release, perform, display, or disclose these technical data [this software] are restricted by paragraph (b)(2) of the Rights in Technical Data - Non-commercial Items [Rights in Non-commercial Computer Software and Non-commercial Computer Software Documentation] clause contained in the above identified contract. No restrictions apply after the expiration date as shown above. Any reproduction of technical data [software] or portionsthereof marked with this legend must also reproduce the marking.

**P-8A**


# **GOVERNMENT PURPOSE AND RIGHTS**

Intentionally Left Blank

**GOVERNMENT PURPOSE AND RIGHTS. Use or disclosure of this information is subject to the restriction(s) on the title page or on the first page of this document.**

P-8A

FLAMMABLE MATERIAL LOCATIONS



GOVERNMENT PURPOSE AND RIGHTS. Use or disclosure of this information is subject to the restriction(s) on the title page or on the first page of this document.

**ACTIONS:**

WHEELS ARE EQUIPPED WITH FUSIBLE PLUGS DESIGNED TO MELT AND DEFLATE THE TIRE WHEN THE TEMPERATURE IS EXCESSIVE.

HOT BRAKES

Normal Cooling (move aircraft to suitable location and allow to cool on their own).

Water Mist: (can be deployed from turret or handline).

Fans (placement of fans may place firefighters very close to the hazard zone).

WHEEL FIRE

Large amounts of water initially with turrets.


Transition to handline application to continue and maintain a cooling effect.

**WARNING: APPROACH LANDING GEAR TRUCK FROM FORWARD OR AFT WHEN FIGHTING A WHEEL FIRE, AS WHEELS AND TIRES MAY EXPLODE.**

P-8A


EMERGENCY RESCUE ACCESS-1

**1 CO-PILOT'S SLIDING WINDOW  
(PILOT'S WINDOW - AS INSTALLED)**




- TO OPEN WINDOW FROM OUTSIDE:
1. PUSH IN EXTERNAL ACCESS DOOR.
  2. PULL EXTERNAL RELEASE HANDLE.
  3. SLIDE WINDOW OPEN.

**2 FWD AND AFT ENTRY DOOR  
EXTERNAL HANDLE (LH SIDE)**



- TO OPEN DOOR:
1. PULL HANDLE OUTWARD.
  2. ROTATE CLOCKWISE.
  3. FORWARD DOOR OPENS OUTWARD, AFT DOOR OPENS INWARD.

**3 FWD SERVICE DOOR  
EXTERNAL HANDLE (RH SIDE)**




- TO OPEN DOOR:
1. PULL HANDLE OUTWARD.
  2. ROTATE COUNTERCLOCKWISE.
  3. PULL DOOR OUTWARD.

WARNING: PASSENGER AND SERVICE DOORS, SLIDE MAY AUTOMATICALLY DEPLOY WHEN DOORS ARE OPENED FROM OUTSIDE

**4 EMERGENCY OVERWING EXIT DOOR**



EXTERIOR OVERWING  
EMERGENCY EXIT  
PUSH PANEL




- TO OPEN DOOR FROM OUTSIDE:
1. HOLD KNEE AGAINST LOWER PORTION OF DOOR.
  2. PUSH IN EXTERIOR OVERWING EMERGENCY EXIT PUSH PANEL.
  3. DOOR OPENS OUT AND UP AUTOMATICALLY.

WARNING: 737-600/700/800/900 MODELS HAVE A SPRING LOADED UPWARD SWINGING OVERWING EXIT DOOR IN LIEU OF A HATCH. FOLLOW THE OPENING PROCEDURE INDICATED ABOVE TO AVOID INJURY.

GOVERNMENT PURPOSE AND RIGHTS. Use or disclosure of this information is subject to the restriction(s) on the title page or on the first page of this document.

P-8A


EMERGENCY RESCUE ACCESS-2



GOVERNMENT PURPOSE AND RIGHTS. Use or disclosure of this information is subject to the restriction(s) on the title page or on the first page of this document.

P-8A

BATTERY LOCATION




BATTERIES ARE ACCESSIBLE FROM  
FORWARD CARGO COMPARTMENT

GOVERNMENT PURPOSE AND RIGHTS. Use or disclosure of this information is subject to the  
restriction(s) on the title page or on the first page of this document.

P-8A


FLIGHT DECK CONTROL SWITCH LOCATIONS



GOVERNMENT PURPOSE AND RIGHTS. Use or disclosure of this information is subject to the restriction(s) on the title page or on the first page of this document.

P-8A

# COMPOSITE MATERIALS LOCATIONS



GOVERNMENT PURPOSE AND RIGHTS. Use or disclosure of this information is subject to the restriction(s) on the title page or on the first page of this document.